

Washing Machine Shaking Violently

Diagnosis and Fix Guide

Check 1: Redistribute load evenly - add balancing items for heavy single pieces

Check 2: Level the machine - adjust all 4 feet, lock with jam nuts

Check 3: Add anti-vibration pads (especially on tile/hardwood floors)

Check 4 (new machines): Remove shipping/transport bolts from rear

Check 5: Listen for grinding/rumbling = bearing failure signal

Check 6: Listen for thudding/clunking = loose counterbalance weight

Shock absorbers: worn if vibration gradually worsened over months

STOP USE if machine moves across floor or bangs cabinet during spin